


SEMATIC AUTOMATIC DOOR CONNECTION DIAGRAM FOR ACT CONTROL PANEL



- 1) CAM terminals (2001-810) are not used if car and landing doors are full-automatic
- 2) If cabin door is automatic and landing doors are manual then:
 - Landing door contacts are serially connected to 120-130 terminals.
 - Car door contacts are serially connected to Car door contact (130-135) terminals.
 - Landing door lock contacts are serially connected to Car door contact (135-140) terminals.

F/7.5.5.02.69

This document is a sample for applications. All information contained in these materials are subject to change by Aybey Elektronik without notice. Aybey Elektronik assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

MERIH, TROMP, HYDRA PLUS AND SEMATIC DOOR CONNECTION DIAGRAM

AYBEY ELEKTRONİK	SERIES	ACT	DRW.	M. AKKUŞ
	PROJ.	ACT063	APPRV.	M. AYBEY
	REV.	00	DATE	22 JUN 10