

\*TRANSFORMER : Until 8 stops, use 200W transformer.  
 For 9-16 stops, use 250W transformer.(0-18-20V coil must be 130W)

**SAFETY LINE**

\*EKS : Emergency Electrical Operator.

**TRANSFORMER / 200W**

**LINE**


**ACT**

**FUJI FRENIC LIFT INVERTER**

**MOTOR**

**OUT BOARD**

**CALLS**



A04 : LIFT TYPE/ 006(FUJI CLOSED LOOP)

This document is a sample for applications. All information contained in these materials are subject to change by Aybey Elektronik without notice. Aybey Elektronik assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

**ACT BOARD WITH FUJI LIFT INVERTER AND MOTOR CONNECTION DIAGRAMS (220V AC)**

<b>AYBEY ELEKTRONİK</b>	SERIES	ACT	DRW.	M. AKKUŞ
	PROJ.	ACT085	APPRV.	M. AYBEY
	REV.	01	DATE	29 MAR 11

F/7.5.5.02.69