



\*TRANSFORMER : Until 8 stops, use 200W transformer.  
 For 9-16 stops, use 250W transformer.(0-18-20V coil must be 130W)  
 \*TRANSFORMER / 200W

\*EKS : Emergency Electrical Operator.

This document is a sample for applications. All information contained in these materials are subject to change by Aybey Elektronik without notice. Aybey Elektronik assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

F/7.5.5.02.69

**CONTACTOR AND MOTOR CONNECTIONS**  
SAFETY VOLTAGE: 48V DC

<b>AYBEY</b> ELEKTRONİK	SERIES ACT006	ACT	DRW. APPRV.	MAKKUS M. AYBEY
	REV. 01	DATE		23 JUN 10